

ASSEMBLY
MANUAL



Go Cart

Dr.Shrink⁺

INTERNATIONAL SHRINK WRAP SUPPLIER



CONTACT OUR WORLD CLASS CUSTOMER SERVICE



315 Washington St.
Manistee, Michigan
49660-1855



P: (800) 968-5147
P: (231) 723-2685
F: (231) 723-9586



www.dr-shrink.com
drshrink@dr-shrink.com

PARTS | Go Cart

Before beginning installation, layout and verify that all parts are included before putting together your Go Cart. If a part is missing, contact us at: 800-968-5147.

A. x8



3/8" Nuts

B. x4



Support Pole D-Clip

C. x2



Caster/Frame

D. x2



Support Poles

E. x2

X-Support Poles



TOOLS | Go Cart

The tools listed here are not included as part of your Go Cart purchase from Dr. Shrink. We recommend having these tools on hand during the construction of your film rack.



Hammer



Socket with 3/8"

STEP-BY-STEP INSTRUCTIONS | Go Cart



Attach X-Support Pole (E) to Caster/Frame (C) using 3/8" Bolts (A). Tighten bolts firmly, but do not completely tighten them down. Repeat Step 1 for the other Caster/Frame (C).



Attach X-Support Pole (E) to the backside of the Caster/Frame (C) using 3/8" Bolts (A). Tighten bolts firmly, but do not completely tighten them down. Repeat Step 1 for the other Caster/Frame (C).



Place Support Poles (D) to Caster/Frame (C) then using Support Pole D-Clip (B). Do this for both Support Poles (D).



Lastly, double check all nuts and bolts used in assembly and be sure they are tightened securely. Tighten any that are not secure.



Dr.Shrink⁺

INTERNATIONAL SHRINK WRAP SUPPLIER

CONTACT OUR WORLD CLASS CUSTOMER SERVICE



315 Washington St.
Manistee, Michigan
49660-1855



P: (800) 968-5147
P: (231) 723-2685
F: (231) 723-9586



www.dr-shrink.com
drshrink@dr-shrink.com

**ASSEMBLY
MANUAL**

Go Cart